



# Sewage Permit Process Background and Guide

[www.nwhu.on.ca](http://www.nwhu.on.ca)

## Program Goal

To ensure installation of private sewage disposal systems comply with Part 8 of the Building Code Act, S.O. 1992 so that human health and the environment are protected.

## Program Description

The Northwestern Health Unit is legislated under the Building Code Act, S.O. 1992 through the *Ministry of Municipal Affairs and Housing* to deliver the **Part 8 Private Sewage Disposal Program**. **Part 8** refers to the section of the Building Code regarding sewage systems. Assigned responsibilities include:

- Issuing permits and performing inspections for sewage systems according to the Building Code. This responsibility includes permits for all private residences and commercial operations with a maximum daily flow rate of 10,000 litres per day or less.
- Inspecting proposed severed lots and land development sites and providing information to the appropriate regulatory authority on the suitability for sewage disposal/treatment.
- Investigating complaints concerning malfunctioning sewage systems. Systems found to be in violation of legislation are followed up for correction.
- Conducting file searches and lot inspections as requested.

The Building Code (Code) requires that sewage systems be designed by certified designers and that they be installed by licensed installers. There is also a provision for homeowners to design and install their own system.

**The Northwestern Health Unit  
does not design sewage systems.**

# Table of Contents

<b>I.</b>	<b>ROLES AND RESPONSIBILITIES FOR THE SEWAGE PERMIT PROCESS</b>	
	A. Owner Responsibilities .....	1
	B. Designer Responsibilities .....	1
	C. Contractor / Installer Responsibilities .....	2
	D. Inspector Responsibilities .....	2
<b>II.</b>	<b>GLOSSARY OF TERMS .....</b>	<b>3-6</b>
<b>III.</b>	<b>SEPTIC SYSTEM INSTALLATION PROCESS .....</b>	<b>7-8</b>
<b>IV.</b>	<b>ON-SITE SEWAGE SYSTEMS</b>	
	A. Class 1 Systems.....	9
	B. Class 2 Systems (Greywater Systems) .....	10
	C. Class 3 Systems (Cesspools).....	10
	D. Class 4 Systems (Septic Systems).....	11
	D1. Septic Systems: Absorption Trench Type Systems.....	11-12
	D1a. Conventional Stone and Pipe Systems .....	12
	D1b. Chamber and other Trench Type Replacement Systems.....	12
	D2. Septic Systems: Filter Bed Systems .....	13
	D3. Septic Systems: Proprietary Systems .....	14
	D3a. Proprietary Air or Media Type Systems with Area Bed.....	14
	D3b. Proprietary Air or Media Type Systems with Shallow Buried Trenches .....	14
	E. Class 5 Systems (Holding Tanks) .....	15
<b>V.</b>	<b>DESIGN PRINCIPLES – CLASS 4 SYSTEMS</b>	
	A. Introduction to Design Principles .....	16
	B. Total Daily Design Sanitary Sewage Flow (Q).....	16
	B1. Residential Occupancy Table.....	17
	B2. Floor Area .....	17
	B3. Plumbing .....	18

## Table of Contents (continued)

### V. DESIGN PRINCIPLES – CLASS 4 SYSTEMS (continued)

C. Soil Types and Percolation Rates .....	19
C1. Determining the Percolation Rate .....	19
C2. Test Holes.....	19
C3. Estimate the Percolation Rate.....	20
C4. Evaluation of Each Test Pit.....	20
D. Clearance Distances .....	21

### VI. DESIGN CALCULATIONS

A. Treatment Units (Septic Tanks).....	22
A1. Tank Volume .....	22
A2. Effluent Filter .....	22
A3. Volume of Dosing Chamber .....	22
B. Soil Based Treatment Systems .....	23
B1. Conventional Stone and Pipe Systems .....	23-24
B2. Chamber and other Proprietary Products Type Systems.....	24
B3. Filter Bed Type Systems .....	24
B3a. Effective Area.....	24
B3b. Extended Base Area .....	25
B3c. Mantle Area .....	25
B4. Area Bed Systems and Shallow Buried Trench Type Systems.....	25
C. Greywater Systems .....	26
C1. Flow Rate for Greywater Systems .....	26
C2. Loading Rate for Greywater Systems .....	26
C3. Sample Design for Greywater Systems .....	26-27
D. Holding Tanks .....	27

# I: ROLES AND RESPONSIBILITIES FOR THE SEWAGE PERMIT PROCESS

## A. Owner Responsibilities

---

The *Owner* of the property, where an on-site sewage system of not more than 10,000 L/d exists or will be installed, is responsible for:

- Signing the Sewage Permit Application to certify that the information is correct;
- Ensuring that the proper **site evaluation** is completed;
- Ensuring that the design of the system complies with the **Code**; and
- Contacting the *Northwestern Health Unit* prior to making any alterations to existing or malfunctioning systems.

In most cases, the property *Owner* will hire an *Installer* or a third-party *Designer* to conduct the site evaluation and design the system on the *Owner's* behalf. The *Installer* or *Designer* will then act as the *Owner's* agent.

## B. Designer Responsibilities

---

The *Designer* of an on-site sewage system is responsible for:

- Conducting the site evaluation to determine site specific information to be utilized for design;
- Conducting discussion with the *Owner* on the use, size, maintenance requirements and appearance of system and components to consider during the design phase;
- Preparing the detailed design, including all design information as required by the Code and the *Northwestern Health Unit*;
- Ensuring design specifications meet all requirements of the Code; and
- Providing support to both the *Owner* and the *Installer* on the principles of the design and any specific requirements for construction as well as operation and maintenance of the system upon completion.

***All Designers must have a valid  
Building Code Identification Number (BCIN).***

## I: ROLES AND RESPONSIBILITIES FOR THE SEWAGE PERMIT PROCESS (continued)

### C. Contractor / Installer Responsibilities

---

A certified *Installer* of on-site sewage systems of not more than 10, 000 litres per day is responsible for:

- Ensuring that a permit has been issued prior to beginning the construction or alteration of a sewage system;
- Reviewing, understanding, and complying with design drawings, specifications, and instructions for the installation of sewage systems;
- Obtaining permission from the system *Designer* prior to making any changes to a design, and informing the *Designer* of any discrepancies in the drawings and specifications, or changes in site conditions;
- Ensuring that all work conducted on the installation is in accordance with the Code;
- Ensuring that all materials used for the installation comply with the Code and specified design requirements; and
- Instructing the *Owner* of the sewage system on the proper use of the system and its maintenance.

***The Installer is not responsible for site evaluation or design of the system, unless he has been specifically contracted to do so. All Installers must have a valid Building Code Identification Number (BCIN).***

### D. Inspector Responsibilities

---

The *Inspector* of an on-site sewage system is responsible for:

- Reviewing the submitted sewage application to ensure it conforms with Northwestern Health Unit policy and the Code;
- Conducting site inspections as required, to verify the information on the sewage application permit; and
- Conducting an inspection to verify that the installation complies with the Code.

***The Inspector is not responsible for the site evaluation, percolation testing, or design of a system.***

## II: GLOSSARY OF TERMS

**Absorption Trench** - Soil based sewage treatment which distributes liquid through piping installed in trenches which are backfilled with clean stone and covered in fill.

**Applicable law** - Legislation that must be complied with or satisfied prior to the issuance of a permit. Requirements with contact information are listed at [www.obc.mah.gov.on.ca](http://www.obc.mah.gov.on.ca).

**Bedroom** - Any room that is designed primarily for sleeping purposes, as shown on the building plan.

**BMEC** - *Building Materials Evaluation Commission* is a committee that researches innovative technologies and materials and authorizes inclusion into the Ontario Building Code.

**Cesspool** - A Class 3 Treatment System - an excavation or pit that is lined or partially lined and is used for disposal of effluent from a Class 1 Composting toilet.

**Clearance Distance** - Required minimum horizontal distance between the two nearest points of property features or structures and sewage treatment elements.

**Code** - Abbreviation for the Ontario Building Code, specifically referencing **Part 8: Sewage Systems**.

**Design Soil** - The fill material used to construct a leaching bed.

**Drainage** - The pattern followed by the waters of an area as they pass or flow off in surface or subsurface streams.

**Dwelling** - A building, usually a residence, equipped with plumbing for domestic use.

**Effluent** - Sanitary sewage that is passed through a treatment unit.

**Effluent filter** - A screened device that must be installed in the outlet of all new septic tanks.

**Erosion** - The wearing away of the land, chiefly by rain, running water or wind. The loosening and transportation of rock debris, soil or sediment.

**Failure** - A condition of on-site sewage system that could constitute a public hazard by inadequate treatment and/or disposal of sewage.

**Fill** - Imported soil.

## II: GLOSSARY OF TERMS (continued)

**Filtration** - The process of passing a liquid through a porous medium for the removal of suspended material from the liquid by a physical straining action.

**Filter Bed** - Soil based sewage treatment which distributes liquid through piping installed in a bed of filter media and clean stone which is then covered with fill.

**Finished Area** - Area within a serviced dwelling that includes installed architectural finishes (drywall, plaster, flooring). This area is used to evaluate projected sewage flow.

**Fixture Unit** - The unit of measure based on the rate of discharge, time of operation, and frequency of use of a fixture that expresses the amount of liquid introduced into the sewage system.

**Greywater** - Wastewater from showers, laundry, and kitchen sinks, excluding toilet wastes.

**Groundwater Table** - The groundwater table is the upper limit of the saturated soil body.

**Hauled Sewage** - Sewage that is transported from a “holding tank” by a licensed hauler for disposal at an approved location.

**Header Line** - A length of pipe with watertight joints installed in a sewage system for the intention of discharging effluent from a septic tank or secondary treatment unit to the distribution pipe in a leaching bed.

**Holding Tank** - A tank designed for the total retention of all sewage released into it and needing intermittent discharging by a hauled sewage system.

**Hydraulic Loading** - The amount of liquid going into a sewage system.

**Impermeable** - A non-porous substance which does not allow the passage or movement of liquid through it.

**Infiltration** - The penetration of water through the soil.

**Leaching Bed** - The soil system constructed as absorption trenches or as a filter bed, located in ground or raised above ground as required by local conditions, to which effluent from a septic tank or secondary treatment unit is applied for treatment and disposal.

## II: GLOSSARY OF TERMS (continued)

**Mantle** - A Code requirement, consisting of an extension of soil fill to provide additional treatment. It consists of soil having a Percolation Rate ( $T_M$ ) of less than 15 min/cm, being at least 250 mm in depth and extending a minimum of 15 metres from the leaching bed in the downward direction of lateral flow.

**MOE** - The *Ontario Ministry of the Environment*.

**Native Soil** - Soil that is original to the site and has not been disturbed.

**Ontario Building Code Act** - The Ontario Building Code Act and its Regulations (Code) are a set of minimum requirements for the safety of buildings with respect to public health, fire protection, and structural sufficiency, by applying uniform standards.

**Percolation Test** - The analysis undertaken to determine the average time required for water levels to drop one centimeter (1 cm) within a saturated soil.

**Percolation Rate (T)** - The amount of time in minutes that is needed for water to drop 1 cm during a percolation test, as established by the test or by other means. It is expressed in Northwestern Health Unit documents as  $T_D$ ,  $T_M$  or  $T_N$  for design, mantle or native percolation rates.

**Percolation** - The gravity flow of water through soil.

**Permeability** - The ability of a soil to transmit liquid, commonly measured as the rate of liquid movement through the soil.

**Porous Soils** - Soils that easily transmit water through them.

**Privy** –Class 1 - A structure used for the sanitary disposal or storage of human wastes without the aid of water carriage.

**Proprietary product** – A commercial sewage system component using patented technology that has achieved BMEC approval.

**Raw Sewage** – Raw sewage includes untreated liquid wastes of domestic origin such as human body wastes, toilet wastes or other bathroom waste, waste from showers and tubs, liquid or water-borne culinary and sink wastes, laundry waste and such other waste as is suitable for treatment.

## II: GLOSSARY OF TERMS (continued)

**Saturation** - The condition where the voids of a material (soil) are filled with a liquid, usually water.

**Septic Tank** - A two-compartment watertight container in which sewage is accumulated with the intention of extracting scum, grease, and solids from the liquid prior to transport to a leaching bed.

**Site Evaluation** - The investigative work required to obtain all site-specific information necessary for sewage system design. This includes design information on the dwelling, soils, drainage and identification of topographical features which impact sewage system design.

**Substantial completion** – A construction milestone where all components of the sewage disposal system have been installed but not yet backfilled. The installed components are to remain exposed until inspected by the Northwestern Health Unit.

**Surface Water** - Water derived from rainwater surface runoff, snow melt, and groundwater discharge, which occurs at the surface (e.g., ponds, streams, rivers, lakes).

**Tertiary Treatment** - Any type of water upgrade that improves treated wastewater to meet stipulated requirements such as Table 8.2.6.6. of the Ontario Building Code.

**Test Pit** - A hole excavated to inspect soil conditions on a property. The hole must be large enough to view soils at least 1.0 metre below the proposed elevation of the bottom of the filter bed or absorption trench. A minimum of two test pits, located within the proposed area of the leaching bed, are required.

**Topography** - The general surface configuration of the land, including relief, features, utilities and structures.

**Topsoil** - The layer of fertile, dark-coloured surface soil that supports growth.

## FAILED INSPECTIONS

Failed site inspections may require a re-inspection at standard Northwestern Health Unit rates.

### III: SEPTIC SYSTEM INSTALLATION PROCESS

- 1) *Owner* obtains copy of Sewage Permit Process Backgrounder and Guide and Northwestern Health Unit Sewage Permit Application Form.
- 2) *Owner* determines appropriate type of system to service proposal.
- 3) *Owner* determines if scope of project is within abilities of applicant or if a qualified third party is required to assume the role of *Designer*. If not the *Owner*, this role can be filled by a qualified and competent third party who holds a valid BCIN and is retained explicitly for this task.
- 4) A **site evaluation** is performed by the *Owner* or *Designer*. This includes a thorough review of topographical features, site **drainage** and subsurface materials and conditions. Soil characterization, including laboratory analysis of all **design soils**, must be performed at this stage.
- 5) The system is designed by *Owner* or qualified *Designer*. The design consists of the completion of all required sections of the Northwestern Health Unit Sewage Permit Application Form, the submission of laboratory results for design soils and a copy of a complete property survey.
- 6) The Application is submitted to Northwestern Health Unit (NWHU) along with the application fee.
- 7) The Application is reviewed by an *Inspector* of the Northwestern Health Unit to determine compliance with the **Code** and to ensure all required information is submitted.
- 8)
  - a. An **on-site inspection** is scheduled to review site features; **OR**
  - b. The Form entitled, Refusal of Application for Sewage System is sent to the applicant requesting either missing information or design that meets the Code. A revised Northwestern Health Unit Sewage Permit Application Form must be submitted and approved prior to scheduling a site inspection.
- 9) A site inspection is scheduled to assess site features with test holes in proposed area provided by *Owner*. A site inspection is to be scheduled within 5 business days of the application review. Actual timing of the inspection may vary due to travel distances.

### III: SEPTIC SYSTEM INSTALLATION PROCESS (continued)

- 10) The area of the proposed system is staked out by *Owner* with **test pits** left available for inspection or new test pits co-ordinated for the scheduled on-site inspection.
- 11) The *Owner*, or representative, attends an **on-site inspection** with a *Northwestern Health Unit Inspector*. The inspection includes confirmation of all site-specific topographical information and sub-surface conditions through the inspection of test holes.

***The Owner, or representative,  
MUST be on site during all inspections.***

- 12) a. The Sewage Permit is issued at site; **OR**  
b. The form entitled, Refusal of Application for Sewage System is issued with details on outstanding requirements. This form will also indicate if re-inspection is required. Resubmitted Application Forms proceed from Step 7, and re-inspection fees may apply.
- 13) Once the Sewage Permit is issued, applicant has system **substantially completed** in accordance with design and Code.
- 14) The *Northwestern Health Unit* is contacted for arranging an inspection of the substantially completed system. All components of the design need to be on-site and installed, but open for inspection.
- 15) The substantially completed system is inspected for compliance with the design and the Code. Measurements and features of the site and the installation are recorded.

***The Owner, or representative,  
MUST be on site during all inspections.***

- 16) Permission to continue with installation is granted by the *Northwestern Health Unit* or form entitled, Refusal of Constructed Treatment Works is issued. Details of non-compliance are identified on the form with the status of re-inspecting the site clearly identified. The *Owner* must ensure all noted items are corrected, all fees are paid and a successful inspection has been completed by the *Northwestern Health Unit* prior to final completion.
- 17) A Certificate of Completion is issued by mail by the *Northwestern Health Unit* within 15 days of final inspection.

## IV: ON-SITE SEWAGE SYSTEMS

The following sections describe briefly the types of systems available and information about each classification. Please consult the **Code** for more complete information.


### A. Class 1 Systems

---

These systems consist of **privies, composting toilets, chemical toilets** and **incinerating toilets**. There are several types of privies such as an earth pit **privy**, a portable privy and a privy vault.

These systems are only for human waste. They are often used in conjunction with a Class 2 System for minimal plumbing as described below. The **Code** includes **clearance distance** requirements for privies to watercourses, property lines, wells and to underlying features such as bedrock and the water table.

Construction requirements for privies specify a minimum amount of soil surrounding the pit (600 mm) and the depth of the pit to underlying groundwater or bedrock (900 mm). Composting toilets are allowed to have sub-floor units with an overflow drain that discharges to a Class 3 **Cesspool**.



## IV: ON-SITE SEWAGE SYSTEMS (continued)

### B. Class 2 Systems (Greywater Systems)

---

**Greywater** is defined as wastewater from sinks, showers, bathtubs and other non-toilet fixtures. A greywater system is a soil-based system that treats and disposes of the wastewater. It can consist of trenches, stabilized pits or porous vessels. However, pits and vessels are frequently too small in sidewall area to be practical.

The Code allows minimal plumbing fixtures to flow to a greywater system as determined by calculating the design flow using predetermined flow rates. Washing machines are restricted from flowing into these types of systems because laundry waste has a very high concentration of fibrous lint that clogs soil based systems prematurely.

The Code specifies two different flow rates, based on the supply of water, to determine the Daily Design Flow Rate. Pressurized supply water is assessed a Design Flow Rate of 200 litres per **fixture unit** of plumbing. A supply of non-pressurized water (water tower) is assessed as having a Design Flow Rate of 125 litres per fixture unit of plumbing. Each sink or shower has a count of 1.5 fixture units.

The Daily Design Flow Rate is used to calculate the sidewall area of a system based on the **percolation** rate of the soil to be used to construct the system. The Code requires:

- A minimum of 600 mm of **design soil** to surround the greywater system;
- A minimum of 900 mm of soil between the underlying bedrock or **groundwater table** and the bottom of where wastewater is applied; and
- A maximum of 1000 litres of design flow per system.

### C. Class 3 Systems (Cesspools)

---

These systems are soil- based systems that treat and dispose of the overflow water from composting toilets. They can be constructed as a trench or as a pit. These systems can be relatively small as the volumes are significantly lower than wastewater from greywater systems.

The Code requires a **minimum clearance distance** of 900 mm from the bottom of the pit or trench to the underlying bedrock or groundwater table. Where a lid extends to the surface, it must be lockable.

## IV: ON-SITE SEWAGE SYSTEMS (continued)

### D. Class 4 Systems (Septic Systems)

These systems are designed to accept all plumbing.


Septic systems consist of a two-compartment septic tank and a soil based absorption system. The downslope area of where the sewage is applied is called the **mantle**. The mantle provides additional area for treatment and is an important component of all septic systems.

All new **septic tanks** must incorporate an **effluent filter** to further protect against solids flowing to the drainfield portion of the system. Documentation about the quality of the soil to be used for the installation must be provided for all septic systems.

#### D1. SEPTIC SYSTEMS: Absorption Trench Type Septic Systems

**Absorption trench type systems** consist of a gridwork of perforated piping that discharges effluent via a distribution box or solid header pipe. Individual distribution lines are installed using 1.6 metre (minimum) centre offsets.

- Conventional stone and pipe trench systems constructed in **native soils**;
- Conventional stone and pipe trench systems in raised, imported soils;
- Chamber type trench systems in native soils;
- Chamber type trench systems in raised, imported soils; and
- Other trench replacement technologies in both native and imported soils.



All of the absorption trench type systems have the same Code requirements:

- Minimum 900 mm from the trench bottom to underlying bedrock or high groundwater table;
- Overall trench length based on the design soil or **Percolation Rate( $T_D$ )**; and
- An imported mantle where the system is constructed with imported **fill**.

## IV: ON-SITE SEWAGE SYSTEMS (continued)


### D. Class 4 Systems (Septic Systems) (continued)

---

#### D1. SEPTIC SYSTEMS: Absorption Trench Type Septic Systems (continued)

##### D1a. CONVENTIONAL STONE AND PIPE SYSTEMS

These systems consist of stone and pipe trenches constructed in either native soils or imported fill. The length of piping required is determined by using the Daily Design Flow Rate and the **percolation rate** of the design soil. The design soil is very important as a moderate sized **dwelling** may require 100 meters of distribution piping in a well-drained sandy soil, but it would require over 400 meters of distribution piping in a heavy clay soil.




A sample layout of a conventional system is appended with calculations.

##### D1b. CHAMBER AND OTHER TRENCH TYPE REPLACEMENT SYSTEMS

Manufacturers have successfully obtained Provincial acceptance of their products through the [Building Materials Evaluation Commission \(BMEC\)](#).

There is a separate [BMEC Authorization Report](#) for each of the approved trench replacements. Trench replacement products include plastic chambers, expanded polystyrene (EPS) chambers and media (geo-synthetic aggregate) containing bundles.



Chamber

## IV: ON-SITE SEWAGE SYSTEMS (continued)

### D. Class 4 Systems (Septic Systems) (continued)


---

#### D2. SEPTIC SYSTEMS: Filter Bed Systems

These systems consist of a conventional septic tank and a relatively small drainfield on top of very specific filter sand. A mantle is required with **filter beds** in poor, native soils.

##### Filter Bed Systems

- **Filter beds** with a septic tank; and
- Filter beds with proprietary treatment.



##### A *filter bed* consists of:

- 750 mm of uniformly graded sand that meets a very specific grain size envelope;
- 300 mm of crushed rock that contains piping on maximum 1.2 meter centers;
- An expanded area of filter sand where the native soil is not sand; and
- A mantle based on the native soil.

##### When the Daily Design Flow Rate is over 3000 liters per day, the following apply:

- The loading rate changes from 75 liters per square meter to 50 liters per square meter;
- Multiple filters (50 m<sup>2</sup>) are required; and
- Proprietary treatment is required for daily design flows in excess of 5,000 litres.

A sample layout of a conventional filter bed system is appended with calculations. A filter sand graph that shows acceptable filter sand is appended.

## **IV: ON-SITE SEWAGE SYSTEMS** (continued)

### **D. Class 4 Systems (Septic Systems)** (continued)

---

#### **D3. SEPTIC SYSTEMS: Proprietary Systems**

##### **D3a. PROPRIETARY AIR OR MEDIA TYPE SYSTEMS WITH AREA BED**

These systems consist of either an air technology or media technology type treatment unit used with a low profile area bed constructed out of clean sand and stone.

An area bed type system consists of a continuous stone layer over top of a sand layer and a downslope mantle as specified in the Code.

##### **D3b. PROPRIETARY AIR OR MEDIA TYPE SYSTEMS WITH SHALLOW BURIED TRENCHES**

These systems consist of either an air technology or media technology type treatment unit used with a network of pressurized, shallow buried trenches. A small diameter pipe, with sufficient holes drilled in it to allow the effluent to spray inside the entire length of the chamber, is suspended inside the entire length of the chamber. There must be a measurable excess of pressure at the end of the system (600 mm).

***All Proprietary Systems have an on-going  
sampling and maintenance requirement.  
They must be designed and installed  
by an authorized agent of the manufacturer.***

## **IV: ON-SITE SEWAGE SYSTEMS** (continued)

### **E. Class 5 Systems (Holding Tanks)**

---

**Holding tanks** are large single compartment tanks used for collection and storage of sewage for removal by a licensed sewage hauler.

**Holding tanks are allowed in limited circumstances:**

1. A municipal sewer is going to be available within a limited time.
2. Temporary facilities, such as construction trailers at industrial sites.
3. To remedy an unsafe existing sewage system where the property is too small for a septic system.

**Requirements for holding tanks include:**

1. The minimum sized tank for any installation is 9,000 litres.
2. All plumbing must be connected into the system.
3. All tanks shall be alarmed with both an audio and visual alarm.
4. Tanks must be anchored if they are subject to lifting by groundwater forces.
5. A contract with a licensed hauler must be obtained for appropriate hauling and disposal of sewage at an approved site.

Holding tanks are sized according to the Daily Design Flow Rate, Q. The capacity of a holding tank is a minimum of seven times the calculated daily flow rate.

## V: DESIGN PRINCIPLES – CLASS 4 SYSTEMS

### A. Introduction to Design Principles

---

#### Systems can be designed by:

- Homeowner for own system; or
- Third party *Designer*.

#### There are two key elements to all designs:

- Total Daily Design Sanitary Sewage Flow (Q); and
- **Percolation Rate (T)** of soil to be used. (*The Northwestern Health Unit has identified the three possible T times as  $T_D$ ,  $T_N$ , and  $T_M$  - for Percolation Rate of Design Soils, Native Soils and Mantle Soil, respectively.*)

#### Scope

The following information is primarily for the design of conventional type systems consisting of a **septic tank** with either a septic field or a **filter bed** system. Proprietary type systems need to be designed by a third party *Designer* who is competent in providing detailed design.

### B. Total Daily Design Sanitary Sewage Flow (Q)

---

#### The flow rate is used:

- To design both the tank and **leaching bed** size of the system; and
- To calculate the size of the **mantle**.

All types of buildings including **dwelling**s are assigned a Daily Design Flow Rate. The **Code** has two tables that list Residential and Non-Residential Occupancies.

For dwellings, a Base Flow Rate (BFR) is first established from the Residential Occupancy Table and potential extra flow is assigned for:

- **Bedrooms** over five; or
- Floor area in excess of 200 m<sup>2</sup>; or
- Plumbing in excess of 20 **fixture units**.

The Code requires that, where multiple calculations of flow are permitted, the highest flow be used.

***Note that guest cabins need to be included in the calculations whether they are plumbed or not - unless there is an approved system servicing them.***

## V: DESIGN PRINCIPLES – CLASS 4 SYSTEMS (continued)

### B. Total Daily Design Sanitary Sewage Flow (Q) (continued)

#### B1. Residential Occupancy Table

RESIDENTIAL OCCUPANCY	VOLUME, LITRES
Apartments, Condominiums, Other Multi-family Dwellings - per person <sup>(1)</sup>	275
Boarding Houses	
a) Per person,	
i) with meals and laundry facilities, or	200
ii) without meal or laundry facilities, and	150
b) Per non-resident staff per 8 hour shift	40
Boarding School - per person	300
Dwellings	
a) 1 bedroom dwelling	750
b) 2 bedroom dwelling	1100
c) 3 bedroom dwelling	1600
d) 4 bedroom dwelling	2000
e) 5 bedroom dwelling	2500
f) Additional flow for	
i) each bedroom over 5,	500
ii) A) each 10 m <sup>2</sup> (or part of it) over 200 m <sup>2</sup> up to 400 m <sup>2</sup> <sup>(2)</sup> ,	100
B) each 10 m <sup>2</sup> (or part of it) over 400 m <sup>2</sup> up to 600 m <sup>2</sup> <sup>(2)</sup> , and	75
C) each 10 m <sup>2</sup> (or part of it) over 600 m <sup>2</sup> <sup>(2)</sup> , or	50
iii) each fixture unit over 20 fixture units	50
Hotels and Motels (excluding bars and restaurants)	
a) Regular, per room	250
b) Resort hotel, cottage, per person	500
c) Self service laundry, add per machine	2500
Work Camp/Construction Camp, semi-permanent per worker	250

#### Notes to Table:

<sup>(1)</sup>Additional flow must be added where more than two people could sleep per bedroom.

<sup>(2)</sup>Total finished area, excluding the area of the finished **basement**.

#### B2. Floor Area

Finished floor area needs to be determined to assign potential additional flow that may need to be added to the Base Flow Rate, BFR. The table above requires that additional flow be added where the **finished area** excluding any finished area in the basement is in excess of 200 square metres. A basement is defined as the floor below the first storey and the first storey is defined as the closest floor to the surrounding grade with its ceiling more than 1.8 metres above that grade. On sloping sites with a walkout basement, a calculation needs to be made to determine where the ceiling is in relation to the average backfill height around the building. On most walkout basements where the backfill on the back wall is to the top of the wall, the finished area in the basement will not need to be added to the design flow. However, plumbing and bedrooms in the basement area still need to be added into the design.

## V: DESIGN PRINCIPLES – CLASS 4 SYSTEMS (continued)

### B. Total Daily Design Sanitary Sewage Flow (Q) (continued)

---

#### B3. Plumbing

The total number of fixture units of plumbing needs to be determined using the following table: Fixture Units of Plumbing. Note that a bathroom group means a group of plumbing fixtures installed in the same room, consisting of one sink, one toilet and either one bathtub (with or without a shower), or one one-headed shower.

Once the number of fixture units is determined, a calculation is performed to assign potential extra plumbing flow. Fifty (50) litres of flow are assigned for each fixture unit over twenty (20) fixture units.

Where additional plumbing connections exist, even without connected fixtures (roughed-in), the fixture unit calculation shall take this into account.

**Fixture Units of Plumbing**

FIXTURE	HYDRAULIC LOAD Fixture Units
Bathroom group	6
Bathtub (with or without shower)	1½
Bidet	1
Clothes washer	1 ½ with 1 ½ in. <i>trap</i>
Dishwasher	½
Laundry tub	
(a) single or double units or 2 single units with common <i>trap</i>	1½
(b) 3 compartments	2
Shower drain	
(a) from 1 head	1½
(b) from 2 or 3 heads	3
(c) from 4 to 6 heads	6
Sink	
(a) domestic and other small type with or without garbage grinders, single, double or 2 single with a common trap	1½
Toilet	4

A complete table of fixture units is available in the Code.

## V: DESIGN PRINCIPLES – CLASS 4 SYSTEMS (continued)

### C. Soil Types and Percolation Rates

---

In order to size the sewage system with the proposed structure, the **Percolation Rate** (T), or the rate at which liquid will move through the soil (expressed in cm/min), will be required.

Percolation Rate ( $T_x$ ) for various soil materials is denoted by the subscript reference for the Sewage Permit. The variables ( $T_D$ ) ( $T_N$ ) ( $T_M$ ) refer to the percolation rates for Design Soil, Native Soil and Mantle Sand, respectively.

#### C1. Determining the Percolation Rate

To determine the Percolation Rate ( $T_x$ ) for a given soil, follow these steps:

- a) Collect a sample of the soil to be analyzed at an accredited laboratory. A laboratory that is a member of the Canadian Council of Independent Laboratories (CCIL) is acceptable to the *Northwestern Health Unit*. The *Northwestern Health Unit* chain of custody document should be used for sample submission. Contact the laboratory for specific sampling requirements. Should the laboratory report list a range of values for percolation rate, the highest value shall apply for design and evaluation purposes.
- b) Perform a percolation test at your site. Any on-site soil testing must be performed and documented by a third-party Certified Soil Technician.

#### C2. Test Holes

**Test holes** will be required to determine subsurface conditions and to properly assess **native soils**. Test holes are required in the area where the proposed sewage treatment system is to be located. A minimum of two test holes is required. The test holes must be dug to a minimum of 1.0 metre below the proposed trench elevation, with a record made of all soil types and any of the following:

1. bedrock, or boulders;
2. clay, or hardpan soil; or
3. the groundwater table.

The Code stipulates that, if you are installing **absorption trench** style leaching bed, the trench depths must be between 600 mm and 900 mm. If your **test holes** are a minimum of 1.0 meters in depth, with none of the above noted restrictions, you should examine the soil in this 600 - 900 mm range. By comparing this soil with the chart on the next page, estimate the percolation rate of this soil.

## V: DESIGN PRINCIPLES – CLASS 4 SYSTEMS (continued)

### C. Soil Types and Percolation Rates (continued)

---

#### C3. Estimate the Percolation Rate

Soil Type	Coarse Gravel, no fines	Gravel, some small rocks	Gravel, Sand Mix, some fines	Sand, uniform, some fines	Sand/Loam Mix	Silty Loam	Clay
T-Time Min/cm	0 – 1	1 – 5	5 – 10	10 – 15	15 – 25	25 – 50	> 50

Following the chart above will provide an estimate only of the actual percolation rate of the soil. Actual on-site soil conditions may significantly alter the actual percolation rate.

***The only reliable method for determining the percolation rate is steps (a) and (b) above.***

#### C4. Evaluation of Each Test Pit

Completion of the “Septic System Application Soil Data Sheet” is required for each **test pit**. The evaluation of each test pit involves recording each distinct soil layer (estimated soil type, colour and depth), evidence of groundwater and point of rejection (bedrock). Any soil layer intended for use in the construction of the sewage system as design soil will require laboratory testing to determine design percolation rate. The test pits will be subject to inspection by the *Northwestern Health Unit* during the initial inspection and must be open for verification.

***Care must be taken to prevent unauthorized access to open pits to prevent injury or death. The installation of protective fencing or ribbons should be considered.***

## V: DESIGN PRINCIPLES – CLASS 4 SYSTEMS (continued)

### D. Clearance Distances

---

The tables below identify minimum **clearance distances** between sewage system units and noted topographical features. The clearance distance is measured as the horizontal distance between the two nearest points.

The location of all sewage treatment components must be clearly marked on the property prior to the initial inspection by the *Northwestern Health Unit Inspector*. This includes the perimeter of piping and the tank location. Clearance distances will be measured by the *Inspector* for both the proposed location and again following construction.

The Code specifies that all clearance distance requirements are increased two metres for every metre the trench or stone is raised above existing grade.

Municipalities may have specific clearance distance, or “setback”, requirements depending on location. Remember to consult with the municipal building inspector to determine if a Zoning By-Law has increased requirements.

#### CLEARANCE DISTANCES FOR CLASS 1,2 AND 3 SEWAGE SYSTEMS

	DRILLED WELLS	DUG WELLS	WATERCOURSE	PROPERTY LINE
Earth Pit Privy	15 m	30 m	15 m	3 m
Privy Vault	10 m	15 m	10 m	3 m
Grey Water System	10 m	15 m	15 m	3 m
Cesspool	30 m	60 m	15 m	3 m

#### MINIMUM CLEARANCE FOR TREATMENT UNITS FOR CLASS 4 OR 5 SYSTEMS

Structure	1.5 m
Well	15 m
Watercourse	15 m
Property Line	3 m

#### MINIMUM CLEARANCES FOR DISTRIBUTION PIPING FOR CLASS 4 OR 5 SYSTEMS

Structure	5 m
Drilled Well	15 m
Dug Well	30 m
Watercourse	15 m
Property Line	3 m

## VI: DESIGN CALCULATIONS

### A. Treatment Units (Septic Tanks)

---

The Code has requirements for tank volume, **effluent filters** and dosing chambers volume. The volume of a tank is calculated as the working capacity. Consult the manufacturer's information to determine working capacity.

The Code classifies both conventional **septic tanks** and proprietary technology type tanks as treatment units. Proprietary type systems are sized according to the Supplementary Guidelines to the Ontario Building Code or in accordance with a Building Material Evaluation Commission Authorization Report.

#### A1. Tank Volume

The Code requires a minimum septic tank of 3,600 litres or twice the Daily Design Flow (Q), whichever is greater. For Non-Residential occupancies the tank size is three times Q or 3,600 litres, whichever is greater.

RESIDENTIAL OCCUPANCY      2 times Q = \_\_\_\_\_ litres  
NON-RESIDENTIAL OCCUPANCY    3 times Q = \_\_\_\_\_ litres

#### A2. Effluent Filter

The Code requires an effluent filter be installed on all new tanks installed through the permit process. Effluent filters are an excellent addition to existing tanks that are already in service.

The septic tank effluent filter required by the Code shall conform to the requirements of NSF/ANSI 46, Evaluation of Components and Devices Used in Wastewater Treatment Systems, and shall be sized and installed in accordance with the manufacturer's recommendations.

***A secured access opening to allow for regular maintenance of the effluent filter shall be provided at the ground surface.***

#### A3. Volume of Dosing Chamber

Dosing is the term used by the Code when either a pump or siphon is required. Where a pump or siphon is required, the pump or siphon shall be designed to discharge a dose of at least 75% of the internal volume of the **distribution pipe** within a time period not exceeding fifteen minutes. This translates to approximately 5 litres per metre of trench.

Proprietary treatment units often have a dosing chamber volume specified by the Supplementary Guidelines to the Code or by the BMEC Authorization Report.

## VI: DESIGN CALCULATIONS (continued)

### B. Soil Based Treatment Systems

---

The **Percolation Rate (T)** and the Flow Rate (Q) are used to calculate the design of all types of soil based systems that are itemized below by the following types:

- Conventional Stone and Pipe
- Chamber and other **Proprietary Products**
- **Filter Bed** and Area Bed
- Shallow Buried Trench

#### B1. Conventional Stone and Pipe Systems

The minimum conventional stone and distribution pipe systems are calculated by using the formula below:

$$L = Q \text{ times } T_D \text{ divided by } 200$$

Where L is the total length of distribution pipe in metres:

- Q is the Daily Design Flow Rate in litres; and
- $T_D$  is the percolation rate of the Design Soil.

The formula  $L = Q \text{ times } T_D \text{ divided by } 300$  ( $L=Q*T_D/300$ ) applies where **effluent** receives additional treatment in accordance with the Code.

#### Mantle

When **fill** is imported to construct a sewage system, there will be an increase in lateral (sideways) effluent movement away from the system. To guard against the effluent breaking out to the surface, the Code requires that there be at least 0.25 metres of acceptable soil cover for at least 15 metres in the direction that this in-ground movement will take place.

A loading rate calculation, based on the **native soil** in the sewage system area, must also be applied to determine the size of the mantle. The Code assigns the following Loading Rates:

#### Loading Rates for Fill-Based Absorption Trenches and Filter Beds

Column 1	Column 2
Percolation Time (TN) of Soil, min/cm	Loading Rates-LRM (L/m <sup>2</sup> /day)
1 < T ≤ 20	10
20 < T ≤ 35	8
35 < T ≤ 50	6
T > 50	4

## VI: DESIGN CALCULATIONS (continued)

### B. Soil Based Treatment Systems (continued)

---

#### B1. Conventional Stone and Pipe Systems (continued)

##### Mantle (continued)

The Daily Design Flow Rate (Q), is divided by the appropriate LRM from the above table to obtain the area of the full system. This calculation includes the area under the primary contact area where the sewage effluent is applied.

A sample permit is appended that shows a calculation with a clay type native soil.

#### B2. Chamber and other Proprietary Products Type Systems

All of these types of systems have individual authorizations under the Building Materials Evaluation Commission (BMEC). The length of trench is calculated using the formula for conventional stone and pipe systems and then applying a factor to either decrease or increase the length of system. The factors range from one-third less system to 20 percent more system.

The requirements for a sand mantle apply to these systems in the same manner as with conventional systems in imported fill. Where fill is used to construct a system with a proprietary product, a sand mantle is required.

#### B3. Filter Bed Type Systems

There are typically three components to be calculated for a filter bed design:

- Effective area of the filter;
- Extended base area of the filter; and
- Mantle area.

##### **B3a. EFFECTIVE AREA**

The effective area of a filter bed is the area where the filter sand and the stone with piping are located. The effective area includes the following requirements:

- Effective area =  $Q / 75 = \underline{\hspace{2cm}}$  m<sup>2</sup> where Q is 3000 litres or less.
- Effective area =  $Q / 50 = \underline{\hspace{2cm}}$  m<sup>2</sup> where Q is over 3000 litres.

The effective area contains 750 mm of filter sand under a continuous layer of stone that contains piping installed on maximum 1.2 metre centres.

Note that there is a requirement to divide the effective area into two cells, separated by a minimum of 5 m, where the effective area is greater than 50 m<sup>2</sup>.

## VI: DESIGN CALCULATIONS (continued)

### B. Soil Based Treatment Systems (continued)

---

#### B3. Filter Bed Type Systems (continued)

##### B3b. EXTENDED BASE AREA

In silty or clay type soils, the filter sand must be increased to a larger area to aid in distribution of the effluent.

The extended base area of a filter is comprised of a layer of filter sand a minimum depth of 250 mm. It is calculated using the formula:

$$A = Q * T_N / 850$$

Where A is the whole area under the filter and the extended area:

- Q is the Daily Design Flow Rate; and
- $T_N$  is the percolation rate of the native soil up to 50 min/cm.

##### B3c. MANTLE AREA

The mantle is calculated by dividing the Daily Design Flow Rate (Q) by the appropriate Loading Rate, LRM. (See B1 - *Conventional Stone and Pipe Systems: Mantle.*)

See the appended sample Sewage Permit for a filter bed system constructed in imported soil.

#### B4. Area Bed Systems and Shallow Buried Trench Type Systems

These systems are used with patented, proprietary technology that makes the effluent cleaner than conventional septic tank effluent. The manufacturer or distributor of the proprietary technology should be consulted for a design that meets the Code.

## VI: DESIGN CALCULATIONS (continued)

### C. Greywater Systems

---

The process to determine the size of a **greywater** system includes flow rate and soils.

1. A determination of the flow rate must be made using fixture units of plumbing in conjunction with the type of supplied water (pressurized or non-pressurized). Note that the maximum flow rate per system is 1,000 litres.
2. A calculation is made, using the soils to be used to construct the system, to determine the loading rate of the soil. This loading rate is used with the flow rate to determine the sidewall area that is required.
3. The calculated sidewall area is then used to design a configuration or layout that has the required sidewall area with a minimum of 600 mm of **design soil** surrounding the configuration or layout.

#### C.1 Flow Rate for Greywater Systems

The Code specifies two different flow rates, based on the supply of water, to determine the Daily Design Flow Rate. Pressurized supply water is assessed a Design Flow Rate of 200 litres per fixture unit of plumbing. A supply of non-pressurized water (water tower) is assessed as having a Design Flow Rate of 125 litres per fixture unit of plumbing. Each sink or shower has a count of 1.5 fixture units.

#### C.2 Loading Rate for Greywater Systems

Once the flow rate is determined, a formula ( $L_R = 400 / T$ ) is used to determine the sidewall area of the system:

- Where  $L_R$  is the loading rate of the sidewalls of the system in litres per square metre; and
- Where T is the design percolation time based on the 600 mm of soil surrounding the system.

#### C.3 Sample Design for Greywater Systems

##### **Step One: DETERMINE FLOW RATE.**

Cabin has kitchen sink, bathroom sink and shower with a pressurized water system. Flow rate is 4.5 fixture units of plumbing multiplied by 200 litres = 900 litres.

## VI: DESIGN CALCULATIONS (continued)

### C. Greywater Systems (continued)

---

#### C.3 Sample Design for Greywater Systems (continued)

**Step Two: CALCULATE LOADING RATE OF SOILS.** A sand with a T time of 5 min./cm is being imported to the site as the native soil is clay. The formula-  $L_R = 400 / T$  is used. 400 divided by 5 = 80 litres per square metre.

**Step Three: USE RESULTS FROM STEP ONE AND STEP TWO.** 900 litres divided by 80 litres per square metre = 11.25 square metres of sidewall area. A trench type system is proposed for this sample, that has a trench height of 300mm. The required sidewall area of 11.25 square metres needs to be divided by both sides of the trench (2 x 300 mm = 600 mm or .6 metres) to obtain the total length of trench required = 18.75 metres of trench.

**Step Four: USE CALCULATION FROM STEP THREE TO DESIGN LAYOUT.** The 18.75 metres of trench could be split into three distribution lines 6.25 metres each. They could be put on 1.6 metre centres that would allow the 600 mm of design sand that is required beside each trench. This would translate into an excavation of 4.4 metres by 7.45 metres to allow for the 600 mm of sand on the outside of the distribution lines. There would be the need for 600 mm of sand under the area with a further 300 mm of the clay soil to any limiting feature such as bedrock or the high **groundwater table**.

### D. Holding Tanks

---

The Daily Design Flow Rate (Q) is multiplied by 7 to determine the minimum volume of tank that is allowed.

**Note:**

1. The minimum sized tank for any installation is a minimum of 9,000 litres.
2. All plumbing must be connected into the system.
3. All tanks shall be alarmed with both an audio and visual alarm.
4. A contract with a licenced hauler must be obtained.

## QUESTIONS ABOUT SEWAGE PERMITS?

Contact a Public Health Inspector at one of these Northwestern Health Unit offices.

#### KENORA

Phone: (807) 468-3147  
or 1-800-830-5978

#### DRYDEN

Phone: (807) 223-3301  
or 1-888-404-4231

#### FORT FRANCES

Phone: (807) 274-9827  
or 1-800-461-3348